For Technical Support:
Call our Technical Service Department
Monday through Friday, 9 a.m. to 5 p.m. (EST)
1-800-TEC-TOYS or 1-800-832-8697
customer_support@enablingdevices.com

Roll and Learn Turtle #4419

USER'S GUIDE

Enabling Devices
50 Broadway
Hawthorne, NY 10532
Tel. 914.747.3070 / Fax 914.747.3480
Toll Free 800.832.8697
www.enablingdevices.com

Colorful Gears!

Press your capability switch and hear colors, action words, sounds and insect names. Turtle has fifty-five different songs, melodies, sounds and phrases. Colorful gears move when you spin them. Encourages discovery and exploration and teaches cause and effect. Size: 10¼"L x 9½"W x 5½"H. Requires 2 AA Batteries. Weight: 1½ lbs.

Operation:

1. Gently turn the Roll & Learn Turtle over to reveal the battery compartment. Carefully remove the small screw from the battery compartment cover using a Phillips head screwdriver, and slide the battery compartment cover off. Observing polarity, install two AA size batteries into the holder. Alkaline batteries must be used only (e.g. Duracell or Energizer brand). Do not use rechargeable batteries or any other type of batteries because they supply lower voltage and the unit will not perform properly. Replace the battery compartment cover and replace the screw.

2. Plug any capability switch into the 1/8" jack located on the side of the Roll & Learn Turtle, make sure the switch is plugged in all the way. There should be no gaps between the connections, if there is a gap the Turtle will stay ON and your switch will have no control over the Turtle.

2. Activate your switch and hear colors, action words, sounds and insect names. Roll & Learn Turtle has fifty-five different songs, melodies, sounds and phrases. Colorful gears move when you spin them. Encourages discovery and exploration and teaches cause and effect.

Troubleshooting:

Problem: The unit fails to operate, or operates incorrectly.

Action #1: Disconnect the power by removing one of the batteries for 20 seconds in order to reset the unit. Re-install the batteries.

Action #2: Check your batteries – There is a 99% chance that either one is installed incorrectly and/or one is weak/dead.

Please Note: When you are finished using Roll & Learn Turtle remove your external switch. This will help prevent false activations and conserve battery life. For prolonged storage we recommend removing the batteries to prevent battery drain and or battery leakage which can cause damage Roll & Learn Turtle's electronics.

Care of the Unit:

Roll & Learn Turtle can be wiped clean with any household multi-purpose, non-abrasive cleaner and disinfectant. We recommend Simple Green, which is a non toxic biodegradable all-purpose cleaner.

Do not use abrasive cleaners, as they will scratch the surface of the unit.

Do not submerge the unit, as it will damage the electrical components.

Rev 7/1/14